

Product News...



Call Parts directly on **01934 853956** or email **info@jpat.co.uk**

ZF6HP26 & 28



N231 27 01 Plastic sump pan & filter assembly.

N231 29 10 Land Rover output shaft.

N231 35 10 Solenoid set (check by box code).

N231 09 01OM Bush kit by Omega.

N231 62 07 Bridge seal.

N231 62 08 Mechatronic sleeve plug.

N190 00 62 Genuine Lifeguard 6.

N212 20 03 Valve body dampers.

N231 64 03 Input Shaft Land Rover.

N231 62 51 Sonnax Zip kit 6HP28.

Full range of Torque converters in stock.