



Iss 27/08/2002

Toyota Landcruiser 85 up, Runner 4x4/ Pickup 85 up, Supra 86 up, Cressida 87 up,
Pickup T100 4x4 93 up. Lexus GS300 & LS400. Volvo 940/960 92 up.
Also called 30-40LE & 30-80LE and Shogun V4AW3

**AISIN-WARNER
A340E, H, & F**

Illus	Description	Year	Part No.	Illus	Description	Year	Part No.
	KITS						
	Master - except Supra with Turbo	86-89	201 01 01		Direct friction 130 X 2.1 X 40T	(4/5)	201 11 04
	Master - only Supra with Turbo	86-89	201 01 02		Direct steel 105 X 2.3 X 6T	(3/4)	201 12 04
	Master - A340E/H AW4		201 01 03		Direct steel - Supra 105 X 1.8 X 6T	(4)	93 - 201 12 12
	Master - transfer case only		201 01 05		Direct steel - Volvo 105 X 3.0 X 6T	(4)	92 - 201 12 09
	Master - Lexus SC300	92-95	201 01 08		Direct steel - selective 105 X 4.0 X 6T	(AR)	201 12 10
	Master - Lexus GS300	93-96	201 01 08		BRAKE BAND		
	Master - Lexus SC400	92-95	201 01 09		Band		201 14 01
	Master - Lexus GS300	early 93	201 01 09		FILTER		
	Master - Volvo 940, 960	91-97	201 01 09		Pickup - two wheel drive Supra		201 27 01
	Overhaul		201 02 01		Pickup - four wheel drive		201 27 02
	Overhaul - A340E/H AW4		201 02 03		Pickup - Volvo & Trooper 3 bolt		189 27 05
	Overhaul - 30-43L Lexus GS300	93-96	201 02 08		Pickup - Trooper & Jeep 4 bolt		201 27 04
	Overhaul - 30-43L Lexus SC300	92-95	201 02 08		BUSHES		
	Overhaul - 30-43L Lexus LS400	90-95	201 02 08		Pump		112 21 01
	Overhaul - 30-43L Lexus SC400	92-95	201 02 08		THRUST WASHERS		
	Overhaul - 30-43L Toyota Supra	89-97	201 02 08		Front gearset planets 0.815" x 0.485" x 0.033"		201 22 22
	Overhaul - 30-43L Volvo 940, 960	91-97	201 02 08		Rear gearset planets 0.920" x 0.490" x 0.030"		201 22 23
	Overhaul - Previa 2 & 4 wheel drive	94-96	201 02 09		ELECTRICAL		
	Overhaul - A343F		201 02 10		Lock up solenoid	(1)	201 35 01
	Overhaul - V4AW3/A340 Montero/Shogun	94-95	201 02 11		Shift solenoid #1 & #2	(2)	201 35 02
	Overhaul - Shogun		201 02 13		Universal shift solenoid kit		201 35 03
	Overhaul - transfer case only		201 02 05		TOOLS		
	Overhaul - transfer case only - Isuzu		201 02 07		Manual A30-40LE		201 33 21
	Overhaul - transfer case only		201 02 12		Manual A30-80LE		201 33 22
	Gasket and seal		201 03 01				
	Shaft sealing ring - transmission only		201 06 01				
	Shaft sealing ring - transfer case		201 06 02				
	Thrust washers - A340E		201 10 01				
	Thrust washers - A340H		201 10 02				
	GASKETS						
	Transmission pan		201 25 01				
	Transfer case pan		201 25 02				
	Filter spacer		201 25 03				
	Filter (upper & lower)	(2)	201 25 04				
	METAL CLAD SEALS						
	Pump		193 15 01				
	Extension 38 x 58 x 10		201 15 02				
	Extension 36 x 58 x 10		201 15 02				
	Manual lever		173 15 06				
	Speedometer		179 15 04				
	Transfer seal 56 x 75 x 12/7		201 15 03				
	Back end seal - Shogun		201 15 06				
	CLUTCH PLATES						
	Overdrive brake friction 165 x 2 x 24T	(3/5)	201 11 01				
	Overdrive brake steel not Volvo 145 x 2 x 6T	(3/5)	201 12 01				
	Overdrive brake steel Volvo only	(3/5)	92 - 201 12 13				
	Overdrive direct friction 125 x 2.1 x 24T	(2)	201 11 02				
	Overdrive direct steel 105 x 2.0 x 14T	(1/2)	201 12 02				
	Fwd frict (not Lexus or Volvo) 125 x 2.1 x 40T	(3/5)	201 11 05				
	Fwd frict (Lexus & Volvo only) 125 x 1.9 x 40T	(7)	201 11 07				
	Fwd frict 125 x 1.97x 40T	(7)	201 11 08				
	Fwd stl (not Volvo) 105 x 2.0 x 8T	(6)	201 12 05				
	Fwd stl (Volvo) 105 x 1.8 x 8T	(6)	189 12 10				
	Fwd stl (Volvo) 105 x 2.3 x 8T	(6)	201 12 16				
	Low & reverse friction 130 x 1.7 x 32T	(6/7)	201 11 03				
	Low & reverse steel 110 X 1.8 X 15T	(6/7)	201 12 03				
	2nd brake friction 132 X 2.05 X 32T	(4/5)	201 11 06				
	2nd brake steel 105 X 2.5 X 16T	(4)	201 12 06				
	2nd brake steel 105 X 1.8 X 16T	(1)	201 12 07				
	2nd brake steel 105 X 4.0 X 16T	A/R	201 12 08				