

Illus	Description	Year	Part No.	Illus	Description	Year	Part No.
	KITS				VACUUM MODULATOR		
	Master	65-69	116 01 01		Single diaphragm screw in		116 28 01
	Master	70-	116 01 02		Single diaphragm push in		116 28 02
	Overhaul	65-69	116 02 01		Dual diaphragm push in		116 28 03
	Overhaul	70-81	116 02 02				
	Gasket & seal	All	116 03 01		HARD PARTS		
	Shaft sealing ring	65-69	116 06 01		Pump gearset		116 29 01
	Shaft sealing ring	70-	116 06 02		Low & Rev servo piston		116 29 04
	Shaft sealing ring	78-	116 06 03				
	Bushings	70-	116 09 02				
	GASKETS						
	Pan (European)		116 25 01				
	Pan (USA)		116 25 02				
	Pump		116 25 03				
	Extension		116 25 04				
	Intermediate servo cover		116 25 05				
	RUBBER COMPONENTS						
	Pump to case lathe cut seal		116 17 01				
	Forward clutch inner	70-	116 17 03				
	High & reverse outer lathe cut seal		116 17 04				
	High & reverse inner	70-	116 17 06				
	METAL CLAD SEALS						
	Converter		116 15 01				
	Extension with boot		116 15 02				
	Extension no boot		116 15 04				
	SHAFT SEALING RINGS						
	Governor	(3)	116 26 03				
	High & reverse clutch cylinder	(2)	116 26 04				
	Forward clutch cylinder	(2)	116 26 05				
	CLUTCH PLATE						
	High & reverse friction (0.090" thick-1964 only)		116 11 04				
	High & reverse friction		116 11 02				
	High & reverse steel		116 12 02				
	High & reverse steel (0.020" O/S)		116 12 03				
	High & reverse pressure	(1) 66-72	116 13 04				
	High & reverse pressure	(1) 66-72	116 13 02				
	High & reverse pressure	(2) 72-74	116 13 02				
	Forward friction		116 11 03				
	Forward steel - dull finish		116 12 01				
	Forward steel normal finish		116 12 02				
	Forward pressure (next to dia spring)		116 13 01				
	Forward pressure		116 13 03				
	Forward diaphragm spring		116 24 01				
	BRAKE BANDS						
	Intermediate rigid 1.3" wide		116 14 05				
	Intermediate rigid		116 14 03				
	Intermediate flexible		116 14 01				
	Intermediate - Flexible "snap-in"		116 14 04				
	Reverse		116 14 02				
	FILTER						
	Pick up	65-69	116 27 01				
	Pick up	70-	116 27 02				
	Pick up deep pan		116 27 03				
	BUSHES & BEARINGS						
	Front pump body		116 21 01				
	Front stator support	70-86	116 21 04				
	Reverse & high clutch drum with lip	70-86	116 21 09				
	Case rear	64-86	116 21 10				
	Low & reverse drum	64-86	116 21 12				
	Extension		116 21 02				