



Iss 01/05/97

3 speed rear wheel drive with lock up.
Ford USA1975 up**FORD C5**

Illus	Description	Year	Part No.	Illus	Description	Year	Part No.
	KITS				Forward friction 115mm x 1.60 x 112T		116 11 03
	Master		148 01 01		Forward steel - dull finish		116 12 01
	Overhaul		148 02 01		Forward steel normal finish		116 12 02
	GASKETS				Forward pressure (next to dia spring)		116 13 01
	Pan		116 25 02		Forward pressure	81-	116 13 03
	Pump	68-	116 25 03		Forward pressure outer		148 13 02
	Extension		116 25 04		Forward pressure inner	81-	148 13 01
	Intermediate servo cover		116 25 05		Forward diaphragm spring		116 24 01
	METAL CLAD SEALS				BRAKE BANDS		
	Converter		116 15 01		Intermediate rigid 1.3" wide		116 14 05
	Extension with boot		116 15 02		Intermediate rigid		116 14 03
	Extension no boot		116 15 04		Intermediate flexible		116 14 01
	SHAFT SEALING RINGS				Intermediate - Flexible "snap-in"		116 14 04
	Governor	(3)	116 26 03		Reverse		116 14 02
	High & reverse clutch cylinder	(2)	116 26 04		FILTER		
	Forward clutch cylinder	(2)	116 26 05		Pick up	65-69	116 27 01
	CLUTCH PLATES				Pick up	70-	116 27 02
	High & reverse friction (0.090" thick-1964 only)		116 11 04		Pick up deep pan		116 27 03
	High & reverse friction		116 11 02		VACUUM MODULATOR		
	High & reverse steel 116mm x 2.00 x 26T		116 12 02		Single diaphragm screw - in		116 28 01
	High & reverse steel 116mm x 2.50 x 26T	64-81	116 12 03		Single diaphragm push - in		116 28 02
	High & reverse steel	(4) 82-			Dual diaphragm push - in		116 28 03
	High & reverse pressure	(1) 66-72	116 13 04				148 28 01
	High & reverse pressure	(1) 66-72	116 13 02		TOOLS		
	High & reverse pressure	(2) 72-74	116 13 02				
	High & reverse pressure outer	81-	148 13 03				

3 speed rear wheel drive no lock up.
Ford USA 1968 to 81**FORD C6**

	KITS				BRAKE BANDS		
	Master	-76	118 01 01		Intermediate - flexible		118 14 01
	Master	76-	118 01 02		Intermediate snap-in		118 14 02
	Overhaul		118 02 01		FILTER		
	Gasket & seal		118 03 01		Pick up	66-74	118 27 01
	Shaft sealing ring		118 06 01		Pick up for deep pan	75-	118 27 02
	Bushes		118 09 01		VACUUM MODULATOR		
	Pump selective thrust washers		118 10 02		Dual diaphragm		118 28 01
	Thrusts - exc pump selective		118 10 03		Single diaphragm		116 28 01
	GASKETS				BUSHES & BEARINGS		
	Pan		118 25 01		Pump body		118 21 01
	METAL CLAD SEALS				Extension		127 21 02
	Converter		116 15 01		HARD PARTS		
	Extension		118 15 02		One way clutch repair kit		118 44 01
	Extension no boot		118 15 03		TOOLS		
	Manual lever		114 15 03		Manual		118 33 20
	CLUTCH PLATES						
	Direct friction (63 square teeth)	(3/4)	118 11 01				
	Direct steel	(3/4)	118 12 01				
	Direct pressure (outer)		118 13 01				
	Forward friction 161mm x 1.60 x 90T	(3/5) 67-76	118 11 02				
	Forward friction 161mm x 2.00 x 90T	(4) 76-	118 11 04				
	Forward steel waved	(3/4) 67-76	118 12 03				
	Forward steel	(4) 76-	118 12 01				
	Forward steel (0.015" O/S)		118 12 04				
	Forward pressure (outer)		118 13 01				
	Forward pressure (inner)		118 13 02				
	Forward diaphragm spring 0.076"	66-76	118 24 01				
	Forward diaphragm spring 0.094"	76 on	118 24 02				
	Reverse friction (square teeth 6.770" dia)	66-	118 11 03				
	Reverse steel 18 splines	(4/6) 66-	118 12 02				