

Illus	Description	Year	Part No.	Illus	Description	Year	Part No.
	KITS						
	Master		118 01 03				
	Overhaul		118 02 03				
	Gasket & rubber		118 03 03				
	GASKETS						
	Pan		118 25 02				
	Pump to case		118 25 03				
	Valve body		118 25 04				
	Manual control		118 25 05				
	Extension to case		118 25 06				
	CLUTCH PLATES						
	Coast friction	(2)	118 11 05				
	Coast steel	(2)	118 12 05				
	Overdrive friction	(2)	118 11 06				
	Overdrive steel	(2)	118 12 06				
	Intermediate friction	(3)	118 11 07				
	Intermediate steel	(2)	118 12 07				
	Direct friction	(3/4)	118 11 08				
	Direct steel	(4)	118 12 08				
	Forward friction	(4)	118 11 04				
	Forward steel	(4)	118 12 01				
	Reverse friction	(5)	118 11 03				
	Reverse steel	(6)	118 12 09				
	TORQUE CONVERTERS						
	High Stall / Code "A" 7.5L petrol		188 30 02				
	High Stall / Code "B" 4.9L petrol		188 30 03				
	Low Stall / Code "C" 7.3L diesel		188 30 04				
	High Stall / Code "E" 5.0 & 5.8L petrol		188 30 05				
	High Stall / Code "F & M" 5.8L petrol		188 30 06				
	High Stall / Code "G & L" 4.9 & 7.5L petrol		188 30 07				
	High Stall / Code "J & K" 7.3L petrol		188 30 08				